Fuse	Amps	Circuits protected
F2.01	5	Transmission Range (TR) sensor
F2.02	5	Audio unit (18808)
F2.03	5	ABS test connector
F2.04	5	PCM power diode, PCM power relay, COPS & Heated Oxygen Sensor (HO2S) relay, Instrument cluster, Inertia Fuel Shutoff (IFS) switch (9D362), Transmission shift selector
F2.05	5	Autolamp sensor, Traction control switch, Transmission shift selector
F2.06	10	Data Link Connector (DLC) (14489)
F2.07	5	Remote keyless entry module (15K602), Powertrain Control Module (PCM) (12A650), Sunload sensor (19E663)
F2.08	5	Park/turn lamp, right front (13411), Side lamp, right front (13411)
F2.09	15	Headlamp, right (13008)
F2.10	5	Park/turn lamp, left front (13411), Side lamp, left front (13411)
F2.11	15	Headlamp, left (13008)
F2.12	10	Passenger Air bag Deactivation (PAD) switch
F2.13	5	Instrument cluster
F2.14	10	Restraints control module (14B321)
F2.15	–	not used
F2.16	5	Heated seat module, passenger side front, Heated seat module, driver side front
F2.17	5	Instrument cluster
F2.18	20	Remote amplifier, front, Audio unit (18808)

Fuse	Amps	Circuits protected
F2.19	20	Instrument cluster
F2.20	10	Electronic Automatic Temperature Control (EATC) module (19980), Instrument cluster, Front Electronic Module (FEM) (13C788)
F2.21	–	not used
F2.22	–	not used
F2.23	–	not used
F2.24	5	Passive anti–theft transceiver module (15607)
F2.25	–	not used
F2.26	3	Windshield wiper motor (17508)
F2.27	10	Audio unit (18808), Power antenna module
F2.28	–	not used
F2.29	5	Electronic Automatic Temperature Control (EATC) module (19980)
F2.30	5	Front Electronic Module (FEM) (13C788)
F2.31	10	Interior/map lamps assembly, front, Glove box lamp (14413), Footwell lamp, right front, Auxiliary Junction Box (AJB), interior, Footwell lamp, left front (13411)
F2.32	20	Cigar lighter, front (15055)
F2.33	10	Front Electronic Module (FEM) (13C788)
F2.34	5	Power mirror adjust switch
F2.35	5	Brake pedal position switch (13480), Brake pressure switch (2B264)