C111

12B637

P66a
Coil On Plug (COP)
1 (12A366)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1024 (LG/WH)	Coil On Plug (COP) 1 (12029), control

C112

12B637

P67a
Coil On Plug (COP)
2 (12A366)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1026 (PK/WH)	Coil On Plug (COP) 2 (12029), control

C113

12B637

P68a
Coil On Plug (COP)
3 (12A366)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1028 (WH/PK)	Coil On Plug (COP) 3 (12029), control

C114

12B637

P69a
Coil On Plug (COP)
4 (12A366)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1030 (DG/VT)	Coil On Plug (COP) 4 (12029), control

C115

12B637

P70a
Coil On Plug (COP)
5 (12A366)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1021 (LG/YE)	Coil On Plug (COP) 5 (12029), control

C116

12B637

P71a
Coil On Plug (COP)
6 (12A366)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1025 (OG/YE)	Coil On Plug (COP) 6 (12029), control