

left front door

14A005		B 5
A172	Door lock unit, driver side front (5421813)	E 1
A215	Driver Door Module – with keyless entry	E 4
A215	Driver Door Module	E 4
A215	Driver Door Module	E 3
A244	Key pad switch assembly (14A626)	B 2
A431	One Touch Down Module	E 4
C501a	with keyless entry	E 4
C501b	with keyless entry	E 4
C501c		E 3
C508		B 3
C510		E 3
C511		A 3
C512		E 2
C519		B 3
C521		B 4
C523		A 4
C524		E 2
C525		D 1
C526a		B 1
C526c		C 1
C526b		A 2
C528		E 4
C530	with keyless entry	A 2
C534		E 2
C560		B 5
M80	Power window motor, driver side front (23395)	E 2
M220		B 5
N216	Seat adjust switch, driver side front (14A701)	B 3
N239	Door ajar switch, driver side front (14018)	B 1
N239	Door ajar switch, driver side front (14018) – without keyless entry	C 1
N239	Door ajar switch, driver side front (14018)	B 1
N409	Exterior rear view mirror switch (17B676)	B 4
N496	Fuel door release switch	E 2
N632	Luggage compartment lid release switch 1	E 2
Y28	Speaker, left front (18808)	A 4