Master window adjust switch (14529) – Navigator (continued)

Component testing procedure

Circuit to test	Connect self–powered test light or ohmmeter to terminals	Move switch to these positions	A good switch will indicate
Power and Ground Checks Before Any Other Tests	6, C3193a and 7, C3193b	Window lockout Off	Closed circuit
	4, C3193a and 1, 2, 3, 5, C3193a, 2, 3, 4, 8 C3193b	Rest	
	6, C3193a and 8, 4, 3, 2, C3193b 1, 2, 3, 5 C3193a	Rest	Open circuit
Driver front window circuit	6, C3193a and 3, C3193b	Up, one–touch up	Closed circuit
	2, C3193b and 4, C3193a		
	6, C3193a and 2, C3193b	Down, one–touch down	
	3, C3193b and 4, C3193a		
	1, C3193b and 4, C3193a	one–touch up, one–touch down	
Passenger front window circuit	6, C3193a and 3, C3193a	Up	Closed circuit
	2, C3193a and 4, C3193a		
	6, C3193a and 2, C3193a	Down	
	3, C3193a and 4, C3193a		
Left rear window circuit	6, C3193a and 8, C3193b	Up	Closed circuit
	4, C3193b and 4, C3193a		
	6, C3193a and 4, C3193b	Down	
	8, C3193b and 4, C3193a		
Right rear window circuit	6, C3193a and 1, C3193a	Up	Closed circuit
	5, C3193a and 4, C3193a		
	6, C3193a and 5, C3193a	Down	
	1, C3193a and 4, C3193a		
Illumination	Connect pin 5, C3193b to 12V DC power and pin 6, C3193b to ground.	Visually inspect switch to verify illumination.	