C11 (BK)

14401

P91
Central Junction
Box (CJB)



F15010

Pin	Circuit	Circuit Function
1	–	not used
2	–	not used
3	–	not used
4	–	not used
5	31S-GE49 (BK/BU)	Ground, switched
6	–	not used
7	15S-LG9 (GN/BK)	Voltage, ignition switch in Start or Run (not overload protected), switched
8	15S-TA38B (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected), switched
9	–	not used
10	30S-TA31 (RD/BK)	Voltage supplied at all times (not overload protected), switched
11	–	not used
12	–	not used
13	31S-GE52 (BK/RD)	Ground, switched
14	31S-TA32 (BK/WH)	Ground, switched
15	8-KA18 (WH)	Sensor signal

C13 (BK)

14401

P91
Central Junction
Box (CJB)



F10052

Pin	Circuit	Circuit Function
1	15-DA1 (GN/YE) +	Voltage, ignition switch in Start or Run (not overload protected)
	15-DA2 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected)
2	15-CF6 (GN/YE)	Voltage, ignition switch in Start or Run (not overload protected)
3	31S-BB16A (BK/RD)	Ground, switched
4	50-BB12 (GY)	Voltage, ignition switch in Start (not overload protected)
5	30-BB9 (RD) +	Voltage supplied at all times (not overload protected)
	30-BB9A (RD)	Voltage supplied at all times (not overload protected)
6	–	not used
7	29-FA13 (OG)	Voltage supplied at all times (overload protected)
8	31S-HB31 (BK/OG)	Ground, switched
9	75-GG14 (YE/BU) +	Voltage: Ignition switch in Accessory or Run
	75-MD15 (YE/GN)	Voltage: Ignition switch in Accessory or Run
10	–	not used