

Deformed (enlarged) female terminals

1 = Enlarged
2 = Normal

Any probe entering the terminal may enlarge the contact spring opening creating an intermittent signal. Insert the correct mating terminal (Location A) from the service kit and feel for a loose fit.



Electrical short inside the harness

1 = Solder coated wire to ground
2 = Harness protective tape
3 = Intermittent short (solder coated wire pierced through the insulation of another circuit)
4 = Grounding foil