Fuse	Amps	Circuits protected
F1.1	60	Central Junction Box (CJB), F2.1, F2.2, F2.3, F2.5
F1.2	30	Central Security Module (CSM), door locks
F1.3	–	not used
F1.4	40	Rear window defrost relay, Rear window defrost grid (left)
F1.5	40	ABS control module (pump)
F1.6	60	Accessory delay
F1.7	20	Daytime Running Lamps (DRL) module
F1.8	20	Engine cooling fan relay, Engine cooling fan motor
F1.9	20	Main light switch, Central Security Module (CSM)
F1.10	30	ABS control module (valves)
F1.11	40	PCM relay contacts, F1.37, F1.38, F1.39, F1.40
F1.12	50	Starter relay, Starter motor, Ignition relay contacts, F2.8, F2.9, F2.10, F2.11, F2.12, F2.13, F2.14
F1.13	40	Trailer tow relay contacts, left & right turn
F1.14	15	With IVD: Driver brake applied relay coil, Driver brake applied relay contacts, ABS control module, Brake stoplamp switch contacts, Redundant pedal switch, Speed control actuator, PCM, Multi-function switch, Park/stop/turn lamps, High mounted stoplamp Less IVD: Brake stoplamp switch, Multi-function switch, Park/stop/turn lamps, High mounted stoplamp
F1.15	10	Powertrain Control Module (PCM), Instrument cluster, Electronic Automatic Temperature Control (EATC) module
F1.16	20	Power point (right rear)
F1.17	20	Rear wiper motor assembly
F1.18	20	Four-wheel drive control module
F1.19	30	Power window motor (left front)
F1.20	30	Trailer electronic brake control module
F1.21	30	Drivers memory seat module
F1.22	20	Multi-func sw, Mn lt sw, CSM, Hi beam rly coil & cont, F1.44, F1.46
F1.23	30	Ignition switch, Ignition switch relay, F1.41, F2.4, F2.15, F2.21, F2.22, F2.25, F2.26, F2.27, F2.29, F2.30
F1.24	20	Horn relay contacts & coil, Horn (low & high pitch), Steering wheel horn switch contacts, PCM, CSM, Low tire pressure module
F1.25	20	Power point console
F1.26	20	Fuel pump relay contacts, IFS switch, Fuel pump driver module

Fuse	Amps	Circuits protected
F1.27	20	Trailer tow lamps relay contacts, Auxiliary Junction Box (AJB)
F1.28	20	Power point console, 2
F1.29	60	Central Junction Box (CJB), F2.16, F2.17, F2.20, F2.23, F2.24
F1.30	30	Windshield wiper motor, Windshield washer pump motor
F1.31	30	Climate controlled seat modules
F1.32	30	Pwr seat sw (rt), Pwr seat mtr asy, Pwr seat lumbar compressor mtr
F1.33	30	Aux A/C relay contacts, Aux blower motor, Frt & rr aux clim sw, Aux blower motor resistor asy
F1.34	20	HID headlamp relay (right) contacts, HID low beam lamp (right frt)
F1.35	20	HID headlamp relay (left) contacts, HID low beam lamp (left frt)
F1.36	40	Blwr mtr rly cont, Frt blwr mtr, Frt blwr mtr speed controller
F1.37	15	TXV cont, Trans hardware unit, A/C clutch rly, Spd control actuator
F1.38	15	Evap emission canister vent valve, Vapor management valve, IMCC-LSRC module, Positive crankcase ventilation heater, EGR system module, Heated oxygen sensor (HO2S) #11, #12, #21, #22, PCM
F1.39	15	Injectors 1, 2, 3, 4, 5, 6, 7, 8, Idle Air Control (IAC) valve
F1.40	15	Powertrain Control Module (PCM), Mass Air Flow (MAF) sensor, Fuel pump relay
F1.41	25	PCM diode, PCM rly, Ign transformer cpctr 1, Ign transformer cpctr 2, Coil-on Plug (COP) 1, 2, 3, 4, 5, 6, 7, 8
F1.42	10	Halogen low beam lamp (right front)
F1.43	10	Halogen low beam lamp (left front)
F1.44	15	Fog lamp relay contacts, Fog lamps (left & right front)
F1.45	2	Brake pressure switch, ABS control module
F1.46	20	High beam lamp, (left & right front)
CB1.62	30	Accessory delay relay, Window adjust switch (Master right front)