C111

12B637

P66
Coil On Plug (COP) 1
(12029)

F02371

Pin	Circuit	Circuit function
1	1024 (LG/WH)	Coil On Plug (COP) 1 (12029), control
2	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)

C112

12B637

P67
Coil On Plug (COP) 2
(12029)

F02371

Pin	Circuit	Circuit function
1	1026 (PK/WH)	Coil On Plug (COP) 2 (12029), control
2	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)

C113

12B637

P68
Coil On Plug (COP) 3
(12029)

F02371

Pin	Circuit	Circuit function
1	1028 (WH/PK)	Coil On Plug (COP) 3 (12029), control
2	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)

C114

12B637

P69
Coil On Plug (COP) 4
(12029)

F02371

Pin	Circuit	Circuit function
1	1030 (DG/VT)	Coil On Plug (COP) 4 (12029), control
2	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)

C115

12B637

P70
Coil On Plug (COP) 5
(12029)

F02371

Pin	Circuit	Circuit function
1	1021 (LG/YE)	Coil On Plug (COP) 5 (12029), control
2	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)

C116

12B637

P71
Coil On Plug (COP) 6
(12029)

F02371

Pin	Circuit	Circuit function
1	1025 (OG/YE)	Coil On Plug (COP) 6 (12029), control
2	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)