C111

12B637

P66
Coil On Plug (COP)
1 (12029)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1024 (LG/WH)	Switched ground

C112

12B637

P67
Coil On Plug (COP)
2 (12029)

* 6.8L
** 5.4L

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	**1026 (PK/WH)	Switched ground
	*1027 (PK/LB)	

C113

12B637

P68
Coil On Plug (COP)
3 (12029)

* 6.8L
** 5.4L

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	*1026 (PK/WH)	Switched ground
	**1028 (WH/PK)	Switched ground

C114

12B637

P69
Coil On Plug (COP)
4 (12029)

* 6.8L
** 5.4L

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	*1141 (YE/BK)	Switched ground
	**1030 (DG/VT)	Switched ground

C115

12B637

P70
Coil On Plug (COP)
5 (12029)

* 6.8L
** 5.4L

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	*1028 (WH/PK)	Switched ground
	**1021 (LG/YE)	Switched ground

C116

12B637

P71
Coil On Plug (COP)
6 (12029)

F02371

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
2	1025 (OG/YE)	Switched ground