Fuse	Amps	Circuits protected
F1.1	20	Power point (19N236)
F1.2	30	PCM power relay
F1.3	30	Headlamp relay, Main light switch (11654), Multifunction switch, Auto-lamp sensor (14A597), F2.26, F2.27, F2.28, F2.16
F1.4	20	Power point, console (19N236)
F1.5	20	Trailer tow relay, parking lamp, Trailer tow relay, reversing lamp
F1.6	15	Side lamp, right front (13411), Park/turn lamp, left front (13411), Park/turn lamp, right front (13411), Park/turn lamp, left rear (13411), Park/turn lamp, right rear (13411), License plate lamp (13550), F2.18
F1.7	20	Central Security Module (15604)
F1.8	30	Central Security Module (15604)
F1.9	15	Tonneau cover control module (14B450), Fog lamp relay
F1.10	20	Fuel pump relay
F1.11	20	Generator
F1.12	20	Power point (19N236)
F1.13	15	A/C clutch relay
F1.14	20	Power point, rear (19G247)
F1.15	–	not used
F1.16	–	not used
F1.17	10	Radio (18806)
F1.18	15	Powertrain Control Module (PCM) (12A650), Mass Air Flow (MAF) sensor (12B579), Fuel injectors, Idle air control valve (IAC) (9F715)
F1.19	10	Trailer tow connector (15A416)
F1.20	10	Trailer tow connector (15A416)
F1.21	–	not used
F1.22	–	not used

Fuse	Amps	Circuits protected
F1.23	15	Evaporative emission (EVAP) canister vent valve (9F945), Vapor management valve, A/C clutch relay, EGR vacuum regulator solenoid (9J459), Inlet Manifold Runner Control (IMRC) module, Automatic transmission module (7G422), Heated oxygen sensors (HO2S)
F1.24	–	not used
F1.25	30	Trailer tow relay, battery charge
F1.26	50	ABS control module (2C219)
F1.27	50	F2.1, F2.2, F2.3, F2.13, F2.15, F2.12, F2.4, F2.14
F1.28	–	not used
F1.29	40	Blower motor relay
F1.30	–	not used
F1.31	30	Seat adjust switch, passenger side front, Lumbar adjust switch, right front
F1.32	30	not used
F1.33	50	Air suspension solid state relay (2C013)
F1.34	30	Climate controlled seat module, driver side, Climate controlled seat module, passenger side
F1.35	40	Ignition switch (11572), F2.8, F2.29, F2.30, F2.23, F2.22, F2.24
F1.36	30	Driver seat module (14C718), Lumbar adjust switch, left front (14B691)
F1.37	40	Ignition switch (11572), F2.5, F2.8
F1.38	30	not used
F1.39	–	not used
F1.40	40	Rear window defrost relay
F1.41	–	not used
F1.42	–	not used
F1.43	30c.b.	Accessory delay relay
F1.44	50	Tonneau cover control module (14B450)