| Fuse | Amps | Circuits protected |
|---|---|---|
| F2.101 | 30A | Electric trailer brakes |
| F2.102 | 30A | Vehicle Security Module (VSM), Power Door Locks |
| F2.103 | 50A | Ignition switch (11572), Run/Start power circuit, Injector Driver Module (IDM) – 6.0L |
| F2.104 | 40A | Rear window defrost, Heated mirrors |
| F2.105 | 30A | Injector Driver Module (IDM) – 7.3L, Fuel heater relay – 6.0L |
| F2.106 | 30A | Windshield wiper motor (17508) |
| F2.107 | 40A | Heater blower motor (19805), Auxiliary A/C relay |
| F2.108 | 40A | Auxiliary Climate Control |
| F2.109 | 30A | Heated seats |
| F2.110 | 50A | Ignition switch (11572), Run power circuit |
| F2.111 | 30A | Transfer case low to high relay, Transfer case high to low relay |
| F2.112 | 30A | Driver seat module (14C718) (with memory), Seat adjust switch, driver side front (14A701) (without memory) |
| F2.113 | 30A | Starter motor (11002) |
| F2.114 | 30A | Seat adjust switch, passenger side front |
| F2.115 | 20A | Trailer battery charge |
| F2.116 | 30A | Ignition switch (11572), Run/Start power circuit |
| F2.601 | 30A c.b. | Accessory delay, Power windows, Power sliding roof |
| F2.602 | 60A | ABS control module (2C219) |