Battery Junction Box (BJB) (14A003), ZETEC engine

Fuse	Amps	Circuits protected
F1.2	15A	Headlamp, left (13008)
F1.3	15A	Headlamp, right (13008)
F1.4	4A	Powertrain Control Module (PCM) (12A650)
F1.5	15A	Heated Oxygen Sensor (HO2S) #21 (9G444), Heated Oxygen Sensor (HO2S) #11 (9G444), Heated Oxygen Sensor (HO2S) #22 (9F472), Heated Oxygen Sensor (HO2S) #12 (9F472), Vapor management valve
F1.6	20A	Fuel pump relay
F1.10	30A	PCM power relay, Powertrain Control Module (PCM) (12A650)
F1.11	15A	Generator
F1.12	15A	Daytime Running Lamps (DRL) module
F1.13	20A	Fog lamp relay
F1.14	25A	ABS control module (2C219), ABS test connector
F1.15	15A	Daytime Running Lamps (DRL) module, Daytime Running Lamps (DRL) relay
F1.16	15A	Power point (19N236)
F1.17	15A	A/C clutch relay
F1.18	15A	Power point, rear (19G247)
F1.19	40A	Starter relay (11450), Ignition relay, Central Junction Box (CJB) (14A068), Accessory delay relay, Ignition switch (11572)
F1.20	40A	Accessory relay, Accessory delay relay, Central Junction Box (CJB) (14A068), Electronic flasher module, Park lamp relay, Subwoofer amplifier (18C804)
F1.21	40A	Central Junction Box (CJB) (14A068), Horn relay, Brake pedal position switch (13480), Deactivator switch, Seat adjust switch, driver side front (14A701), Four–wheel drive relay
F1.22	30A	Rear window defrost relay
F1.23	40A	Blower motor relay
F1.24	60A	ABS control module (2C219), ABS test connector
F1.25	40A	High speed fan control relay 2
F1.26	40A	Low speed fan control relay