Central Junction Box (CJB) (14A068)

Fuse	Amps	Circuits protected
F19	7.5	Mirror motor, driver side, Mirror motor, passenger side
F20	10	Rear window wiper motor, Windshield wiper relay, Wiper/washer switch, Windshield wiper motor (17508)
F21	40	Inertia Fuel Shutoff (IFS) switch (9D362), Door lock/unlock switch, driver, One–touch window relay, Sliding roof opening panel unit, Window operating switch, passenger side front, Window operating switch, driver side front
F22	7.5	ABS control module (2C219)
F23	15	Air temperature actuator, Gearshift lever unit, Heater mode switch, Multifunction switch, Speed control module, Park/neutral position (PNP) switch, Tailgate ajar relay 1, Tailgate ajar relay 2, Transmission range sensor
F24	15	Brake pedal position switch (13480), Stoplamp switch
F25	20	Anti–theft/central locking module, Gearshift lever unit
F26	7.5	Light switch, Multifunction switch
F27	15	Cigar lighter, front (15055)
F28	30	Data Link Connector (DLC) (14489), Power seat switch, driver
F29	30	Rear window defrost grid (18C618), Rear window defrost switch (18578)
F30	7.5	Anti–theft/central locking module, Display assembly, auxiliary warning system, Gearshift lever unit, Instrument cluster, Instrument interface module Traction Control System (TCS) disable switch
F31	7.5	Belt minder module, Glove box lamp (14413), Headlamp switch panel illumination lamp, License plate lamp, left, License plate lamp, right
F32	– –	not used
F33	7.5	Side lamp, left front (13411), Headlamp, left (13008), Lamp assembly, left rear (13405)
F34	7.5	Interior lamp, front, Instrument cluster, Luggage compartment lamp (13A756), PATS indicator, Power mirror adjust switch, Vanity mirror lamp, left (04100), Vanity mirror lamp, right (04100)
F35	7.5	Side lamp, right front (13411), Headlamp, right (13008), Lamp assembly, right rear (13404)
F36	15	Radio (18806)
F37	30	Heater blower relay
F38	7.5	Air bag diagnostic monitor