Components — Cell 151

	Location	Page/coordinates
A7	ABS control module (2C219) inside frame rail, LH side	10 – E 4
A17	Electronic flasher module Steering Column, LH side	8 – F 2
A19	Warning buzzer/chime module behind dash panel	8 – F 4
A30	Instrument cluster behind dash panel, LH side	9 – E 4
A52	Wiper Control Module (WCM) behind dash panel	8 – F 3
A147	Powertrain Control Module (PCM) (12A650) Steering Column, LH side	7 – F 2
A406	Hydro max module Steering Column, RH side	8 – B 5
A434	4R100 transmission transmission, RH side	1 – F 4
B8	Throttle Position Sensor (TPS) (9B989) engine, top	1 – B 2
B14	Wheel speed sensor, right front (2C204) behind wheel, front, RH side	3 – E 3
B15	Wheel speed sensor, left front (2C205) behind wheel, front, LH side	7 – F 3
B16	Wheel speed sensor, right rear vehicle rear end, RH side	
B17	Wheel speed sensor, left rear vehicle rear end, LH side	
B22	Mass Air Flow (MAF) sensor (12B579) in air cleaner assembly	6 – E 2
B25	Rear axle speed sensor (4B409) vehicle rear end – J3231 !!! No Data Found !!!	10 – B 3
B41	Camshaft position sensor (6B288) engine, front, LH side	2 – B 1
B43	Crankshaft position sensor (6C315) engine, front, RH side	4 – B 5
B44	Turbine shaft speed sensor (7M101) transmission, top	1 – C 5
B45	Knock sensor (12A699) engine, rear, RH side	2 – E 4
B47	Heated Oxygen Sensor (HO2S) #21 (9G444) engine, rear, LH side	2 – F 4
B48	Heated Oxygen Sensor (HO2S) #11 (9G444) engine, rear, RH side	2 – E 5
B110	Output Shaft Speed (OSS) sensor (7M101) transmission, top	1 – F 5
B135	Cylinder–head temperature sensor (6G004) top, front, Left, cylinder head	
B227	Engine Coolant Temperature (ECT) sender engine, top, LH side	2 – B 2
B234	Digital Transmission Range (DTR) sensor (7F293) transmission, LH side	1 – F 3
D20	Data Link Connector (DLC) (14489) Steering Column, RH side	7 – B 4
F1.1	in Battery Junction Box (BJB)	
F1.2	in Battery Junction Box (BJB)	
F1.3	in Battery Junction Box (BJB)	
F1.4	in Battery Junction Box (BJB)	
F1.5	in Battery Junction Box (BJB)	
F1.6	in Battery Junction Box (BJB)	
F1.7	in Battery Junction Box (BJB)	
F1.8	in Battery Junction Box (BJB)	
F1.9	in Battery Junction Box (BJB)	
F1.10	in Battery Junction Box (BJB)	
F1.11	in Battery Junction Box (BJB)	
F1.12	in Battery Junction Box (BJB)	
F1.13	in Battery Junction Box (BJB)	
F1.14	in Battery Junction Box (BJB)	