WARNING
DO NOT ATTEMPT TO DIAGNOSE OR TROUBLESHOOT AIR BAG CIRCUITRY WITHOUT CONSULTING THE WORKSHOP MANUAL. IMPROPER TROUBLESHOOTING COULD CAUSE THE AIR BAGS TO DEPLOY INADVERTENTLY, CAUSING INJURY.

HOT IN START OR RUN

10 "AIR BAG" INDICATOR 8 ** 9

INSTRUMENT CLUSTER
PAGE 62-2

SEE INSTRUMENT CLUSTER
PAGE 62-2

*** SHORTING BARS CONNECT HARNESS TERMINALS WHEN THE HARNESS IS DISCONECTED**
**** COUPE**

952 **PK/GN** **C254** ***SHORTING BAR** 0V **C264**

SOLID STATE

7 AIR BAG INDICATOR CONTROL
21 GROUND

AIR BAG DIAGNOSTIC MONITOR
151–6 E10

OBD CONNECTOR 19
STEERING COLUMN AIR BAG FEED MONITOR 1
STEERING COLUMN AIR BAG RETURN 15
PASSENGER AIR BAG RETURN 14
PASSENGER AIR BAG FEED MONITOR 28

529 OG/BU
151–7 C1 **C233M** **C233F**
529 OG/BU
S235
529 OG/BU
C255
7
DATA LINK CONNECTOR (DLC)
PAGES 23-7, 24-9

SEE ENGINE CONTROLS
PAGES 23-7, 24-9

941 LG ***SHORTING BAR** 942 BU
C267F **C267M**
***SHORTING BAR**
AIR BAG SLIDING CONTACT
151–7 F4
C268M **C268F**
***SHORTING BAR**
DRIVER AIR BAG
151–7 A8

943 YE/RD ***SHORTING BAR** 944 RD
C264
C266M **C266F**
***SHORTING BAR**
PASSENGER AIR BAG
151–6 A8

Electrically connects steering wheel controls to body harness.

57 BK
151–7 C1 **C233M** **C233F**
57 BK
C224
JOINT CONNECTOR #3
PAGE 10-3
G224

SEE GROUNDS
PAGE 10-3

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.