Central Junction Box (CJB)

		Fuse number										
		30	**31**	**32**	**33**	**34**	**35**	**36**	**37**	**38**	**39**	**40**
		10A	15A	15A	20A	20A	7.5A	7.5A			15A	10A
206-09A-00	Anti–Lock Control											
206-09C-00	Anti–Lock Control – Stability Assist							●				
303-03-00	Engine Cooling											
303-04B-00	Fuel Charging and Controls – ZETEC–E											
303-04E-00	Fuel Charging and Controls – SPI											
303-04G-00	Fuel Charging and Controls – Duratec–ST											
303-06-00	Starting System											
303-07B-00	Engine Ignition – ZETEC–E											
303-07E-00	Engine Ignition – SPI											
303-07G-00	Engine Ignition – Duratec–ST											
303-14B-00	Electronic Engine Controls – ZETEC–E											
303-14E-00	Electronic Engine Controls – SPI											
303-14G-00	Electronic Engine Controls – Duratec–ST											
310-03-00	Vehicle Speed Control											
412-02A-00	Heating and Ventilation							●				
412-03A-00	Air Conditioning							●				
413-00-00	Instrument Cluster and Panel Illumination	●										
413-01-00	Instrument Cluster											
413-06-00	Horn				●							
414-02-00	Generator and Regulator											
415-01-00	Audio Unit		●									
415-03-00	Speakers											
417-01-00	Exterior Lighting	●										●
417-02-00	Interior Lighting						●	●				
417-04-00	Daytime Running Lamps	●										
418-00-00	Module Communications Network											
419-01A-00	Anti–Theft – Active											
		30	**31**	**32**	**33**	**34**	**35**	**36**	**37**	**38**	**39**	**40**
		10A	15A	15A	20A	20A	7.5A	7.5A			15A	10A