Central Junction Box (CJB)

		Fuse number										
		30	31	32	33	34	35	36	37	38	39	40
		7.5A	15A	10A	15A	20A	7.5A	7.5A			10A	
206-09A-00	Anti–Lock Control	●										
206-09B-00	Anti–Lock Control – Anti–Wheelspin Control	●										
206-09C-00	Anti–Lock Control – Anti–Wheelspin Control and Interactive Vehicle Dynamics (IVD)	●						●				
303-03-00	Engine Cooling											
303-04D-00	Fuel Charging and Controls – ZETEC–E											
303-04E-00	Fuel Charging and Controls – SPI											
303-06D-00	Starting System – ZETEC–E											
303-06E-00	Starting System – SPI											
303-07D-00	Engine Ignition – ZETEC–E											
303-07E-00	Engine Ignition – SPI											
303-14D-00	Electronic Engine Controls – ZETEC–E											
303-14E-00	Electronic Engine Controls – SPI											
310-03-00	Vehicle Speed Control											
412-00-00	Climate Control System – General Information							●				
412-02-00	Heating/Defrosting							●				
413-00-00	Instrument Cluster and Panel Lighting – General Information			●								
413-01-00	Instrument Cluster											
413-06-00	Horn					●						
414-02-00	Generator and Regulator											
415-01-00	Audio Unit		●									
415-03-00	Speakers											
417-01-00	Exterior Lighting			●	●						●	
417-02-00	Interior Lighting						●	●				
417-04-00	Daytime Running Lamps			●								
418-00B-00	Module Communications Network, Diagnostic											
419-01A-00	Anti–Theft – Active											
419-01B-00	Anti–Theft – Passive				●							
419-10-00	Multifunction Electronic Control Modules							●				
		30	**31**	**32**	**33**	**34**	**35**	**36**	**37**	**38**	**39**	**40**
		7.5A	15A	10A	15A	20A	7.5A	7.5A			10A	