-1



Gauges and Warning Devices (non integral to the cluster)
413-09-00

Instrument Panel and Console
501-12-00

Instrument Cluster and Panel Lighting – General Information
413-00-00

Climate Control System – General Information
412-00-00

Audio System – General Information
415-00-00

Vehicle Emergency Message System
419-05-00

Cellular Phone
419-08-00

Steering Column – General Information
211-00-00

Steering Column
211-04-00

Roof Opening Panel
501-17-00

Rear View Mirrors
501-09-00

Interior Lighting
417-02-00

Horn
413-06-00

Instrument Cluster
413-01-00

Information and Message Center
413-08-00

Wiper and Washer
501-16-00

Fuel Charging and Controls
303-04-00

Starting System
303-06-00

Engine Ignition
303-07-00

Electronic Engine Controls
303-14-00

Vehicle Speed Control
310-03-00

Module Communications Network
418-00-00

Exterior Lighting
417-01-00

Anti–Theft – Active
419-01A-00

Anti–Theft – Passive
419-01B-00

Seating
501-10-00

Glass, Frames and Mechanisms
501-11-00

Keyless Entry/Computer Operated Locks
501-14B-00

Occupant Restraints – Passive – Supplemental Air Bag System
501-20B-00

Anti–Lock Control
206-09A-00

Anti–Lock Control – Traction Control
206-09B-00

Anti–Lock Control – Traction Control and Stability Assist
206-09C-00

Brake System – General Information
206-00-00

Engine Cooling
303-03-00

Charging System – General Information
414-00-00

Automatic Transmission/ Transaxle
307-01-00

Automatic Transaxle/ Transmission External Controls
307-05-00