C1294

A3–288

Compuvalve module



* CNG
** LPG

Pin	Circuit	Circuit function
1	G001 (WH)	Coolant solenoid, signal
2	G002 (WH)	Voltage supplied at all times (overload protected)
3	*G003 (WH)	Tank valve 1, control
	**G003 (WH)	Lock off solenoid, control
4	G004 (WH)	Reference voltage
5	G005 (WH)	Fuel pump cutoff relay, control
6	*G006 (WH)	Fuel tank pressure transducer sensor (9C968), signal
	**G006 (WH)	Liquid Propane Gas (LPG) sender, signal
7	G007 (WH)	Cold start heater relay, control
8	*G008 (WH)	Fuel tank pressure transducer sensor (9C968), Signal return
	**G008 (WH)	Liquid Propane Gas (LPG) sender, Signal return
9	G009 (WH)	Voltage supplied in Start and Run (overload protected)
10	G010 (WH)	Heated Oxygen Sensor (HO2S) #21 (9F472), signal
11	G011 (WH)	Voltage supplied in Start and Run (overload protected)
12	G096 (WH)	not used
13	G013 (WH)	Voltage supplied in Start and Run (overload protected)
14	G086 (WH)	SCP Bus +
15	G015 (WH)	not used

Pin	Circuit	Circuit function
16	G085 (WH)	SCP Bus –
17	G017 (WH)	Low flow injector 1, control
18	G018 (WH)	not used
19	G019 (WH)	Low flow injector 2, control
20	–	not used
21	G021 (WH)	signal, return
22	G022 (WH)	Throttle Position Sensor (TPS) (9B989), signal
23	–	not used
24	G026 (WH)	not used
25	–	not used
26	G026 (WH)	Fuel tank temperature sensor, signal
27	G027 (WH)	not used
28	–	not used
29	–	not used
30	G030 (WH)	Heated Oxygen Sensor (HO2S) #11 (9F472), signal
31	–	not used
32	G032 (WH)	signal, return
33	–	not used
34	G830 (WH)	Crankshaft position sensor (6C315) –
35	–	not used
36	–	not used
37	–	not used
38	G831 (WH)	Crankshaft position sensor (6C315) +

Pin	Circuit	Circuit function
39	–	not used
40	–	not used
41	–	not used
42	G042 (WH)	not used
43	G043 (WH)	not used
44	–	not used
45	G045 (WH)	High flow injector 3, control
46	G046 (WH)	Indicator light switch, return
47	G047 (WH)	High flow injector 4, control
48	–	not used
49	G049 (WH)	High flow injector 5, control
50	G050 (WH)	Indicator light switch, switch, output
51	G051 (WH)	High flow injector 6, control
52	G052 (WH)	Indicator light switch, indicator, control
53	G053 (WH)	High flow injector 7, control
54	G054 (WH)	not used
55	G055 (WH)	High flow injector 8, control
56	G056 (WH)	not used
57	G057 (BK)	Ground
58	G058 (WH)	not used
59	G059 (BK)	Ground
60	G060 (WH)	not used
61	G061 (BK)	Ground
62	G062 (BK)	Ground
63	G063 (BK)	Ground
64	G064 (BK)	Ground