EXCURSION

* SHORTING BARS CONNECT HARNESS TERMINALS WHEN THE HARNESS IS DISCONNECTED.

REVISED

MULTIPLEX COMMUNICATION NETWORK
PAGE 14-1

70 LB/WH → C223

Warning
Do not attempt to diagnose or troubleshoot air bag circuitry without consulting the Workshop Manual. Improper troubleshooting could cause the air bags to deploy inadvertently, causing injury.

AIR BAG DIAGNOSTIC MODULE 151–8 F6

19 ISO 9141 LINK

DRIVER AIR BAG FEED MONITOR 1	DRIVER AIR BAG RETURN 15	SOLID STATE	PASSENGER AIR BAG FEED MONITOR 14	PASSENGER AIR BAG RETURN 28	DEDICATED GROUND 22

0V C223

1203 BK/LB

* SHORTING BAR

614 GY/OG — 615 GY/WH

C238F C238M

* SHORTING BAR

* SHORTING BAR

607 LB/OG — 616 PK/BK

C220F C220M

* SHORTING BAR

AIR BAG SLIDING CONTACT

PASSENGER AIR BAG 151–8 C10

C224F C224M

* SHORTING BAR

DRIVER AIR BAG 151–8 F2

Electronically connects steering wheel controls to body harness.

S202

SEE GROUNDS *PAGE 10-8*

1203 BK/LB

G203