## System Codes -12

### Powertrain Engine Control Gas/Diesel Connections

RA: Connectors
RB: Destination notes
RD: Diodes, fuses, indicators, resistors, heaters
RE: Modules, controllers
RG: Motors
RH: Relays
RJ: Sensors
RL: Solenoids
RN: Splices / Busbars
RP: Switches
RR: Transformers
RS: Units

### Powertrain Transmission Control Systems

TA: Transmission controls
TC: Automatic Clutch
TD: Axle/differential
XL: Temporary numbering for future features