-1

Fuel Charging and Controls – ZETEC–VCT
303–04A–00

Fuel Charging and Controls – Duratec–VE
303–04B–00

Starting System
303–06–00

Engine Ignition – ZETEC–VCT
303–07A–00

Engine Ignition – Duratec–VE
303–07B–00

Electronic Engine Controls – ZETEC–VCT
303–14A–00

Electronic Engine Controls – Duratec–VE
303–14B–00

Automatic Transaxle/ Transmission External Controls
307–05–00

Vehicle Speed Control
310–03–00

Instrument Panel and Console
501–12–00

Multifunction Electronic Control Modules
419–10–00

Speakers
415–03–00

Audio Unit
415–01–00

Horn
413–06–00

Instrument Cluster
413–01–00

Instrument Cluster and Panel Illumination
413–00–00

Air Conditioning
412–03–00

Heating and Ventilation
412–02–00

Rear View Mirrors
501–09–00

Interior Lighting
417–02–00

Module Communications Network – Data Link Connector (DLC)
418–00–00

Wipers and Washers
501–16–00

Roof Opening Panel
501–17–00

Exterior Lighting – License Plate Illumination
417–01–00–9



Exterior Lighting – Stop Lamps
417–01–00–2

Exterior Lighting – Reversing Lamps
417–01–00–12

Seating
501–10–00

Exterior Lighting – Headlamps
417–01–00–1

Exterior Lighting – Turn Signal and Hazard Lamps
417–01–00–3

Exterior Lighting – Position and Parking Lamps
417–01–00–6

Exterior Lighting – Fog lamps
417–01–00–11

Daytime Running Lamps
417–04–00

Engine Cooling – ZETEC–VCT
303–03–00

Engine Cooling – Duratec–VE
303–03–00

Generator and Regulator
414–02–00

Anti–Lock Control
206–09A–00

Anti–Lock Control – Traction Control
206–09B–00

Glass, Frames and Mechanisms
501–11–00

Occupant Restraints – Passive – Supplemental Air Bag System
501–20B–00

Anti–Theft – Active
419–01A–00

Anti–Theft – Passive
419–01B–00

Handles, Locks, Latches and Mechanisms
501–14A–00

Keyless Entry/Computer Operated Locks
501–14B–00