C141 (WH)

14A103

B208
Heated Oxygen Sensor (HO2S), front



F03129

Pin	Circuit	Circuit function
1	ES90 (BK)	Heated Oxygen Sensor (HO2S), front, heater
2	AV19 (LG)	signal, return
3	AV91 (BU/YE)	Voltage supplied in Start and Run (overload protected)

C142 (GY)

12A522

R57
Resistor



F02147

Pin	Circuit	Circuit function
1	AV94 (GN)	Distributor, Ignition coil, return
2	AV03 (WH)	Distributor, Ignition coil, return

C143 (BK)

12A522

N96
Power steering pressure switch

F01035

Pin	Circuit	Circuit function
1	AV12 (PK)	Power steering pressure switch, input

C144 (WH)

12B637

B208
Heated Oxygen Sensor (HO2S), front



F03129

Pin	Circuit	Circuit function
1	ES10 (BK)	Heated Oxygen Sensor (HO2S), front, heater
2	AW30 (LG)	signal, return
3	AW31 (BU/YE)	Voltage supplied in Start and Run (overload protected)

C146a (GY)

12A522

P54
Distributor



F06189

Pin	Circuit	Circuit function
1	AV01 (BU)	Distributor, Transistor, return
2	EP90 (BK)	Ground
3	AV30 (WH)	Camshaft position sensor (6B288), return
4	AV31 (OG)	Camshaft position sensor (6B288), input
5	AV78 (BK/WH)	Voltage supplied in Start and Run (overload protected)
6	ES93 (BK/RD)	Ground