
1
2
3
4
5
6
7
8
A
B
C
D
E
F
C504a
C504b
Master window adjust switch (14529)
C522
Exterior rear view mirror, left
C505
Door lock switch, driver side (14028)
C511
C527
Exterior rear view mirror switch (17B676)
14K138
C500
Key pad switch assembly
C503
Memory set switch (14776)
C526
Door ajar switch, left front
14A488
C525
Door lock actuator, left front
C523
Speaker, left front (18808)
C509
Anti–theft inhibit switch
C524
Power window motor, driver side front (23395)
C510
front of vehicle
driver door