Battery Junction Box (BJB) (14A003), 2.3L

Fuse	Amps	Circuits protected
F1.1	50A	Central Junction Box (CJB) (14A068)
F1.2	–	not used
F1.3	–	not used
F1.4	–	not used
F1.5	–	not used
F1.6	50A	ABS control module (2C219)
F1.7	30A	PCM power relay
F1.8	20A	Central security module
F1.9	–	not used
F1.10	–	not used
F1.11	50A	Starter relay (11450), Ignition switch (11572)
F1.12	20A	Window safety relay
F1.13	–	not used
F1.14	–	not used
F1.15	–	not used
F1.16	40A	Blower motor relay
F1.17	20A	Engine cooling fan relay
F1.18	–	not used
F1.19	–	not used
F1.20	–	not used
F1.21	10A	Powertrain Control Module (PCM) (12A650)
F1.22	–	not used
F1.23	20A	Fuel pump relay
F1.24	30A	Multifunction switch, Main light switch
F1.25	10A	A/C clutch relay
F1.26	–	not used
F1.27	–	not used
F1.28	30A	ABS control module (2C219)
F1.29	–	not used

Fuse	Amps	Circuits protected
F1.30	15A	Trailer tow relay
F1.31	20A	Daytime Running Lamps, Fog lamp relay
F1.32	–	not used
F1.33	15A	Main light switch (11654), Central security module
F1.34	–	not used
F1.35	–	not used
F1.36	–	not used
F1.37	–	not used
F1.38	10A	Headlamp, left (13008)
F1.39	–	not used
F1.40	–	not used
F1.41	20A	Evaporative emission (EVAP) canister vent valve (9F945), Heated Oxygen Sensor (HO2S) #11 (9F472), Heated Oxygen Sensor (HO2S) #12 (9G444), EGR stepper motor, Swirl control solenoid valve, Electronic thermostat, 5R44E Transmission
F1.42	10A	Headlamp, right (13008)
F1.43	17Ω	Resistor
F1.44	–	not used