

left front door

14631	B 5	C526	A 5
A244 . Key pad switch assembly	A 1	C527	B 5
C500	A 1	M80 . Power window motor, driver side front	F 2
C502	B 1	M220 Exterior rear view mirror, driver side	C 5
C504a	B 1	M241 Door lock actuator, left front	A 5
C504b	C 1	N84 . Door ajar switch, left front	A 5
C505	C 5	N204 . Door lock switch, driver side	C 5
C510	F 3	N254 . Lock cylinder switch, left	B 1
C513	E 5	N409 . Exterior rear view mirror switch	B 5
C520	C 5	N447 . Master window adjust switch	B 1
C523	C 1	N447 . Master window adjust switch	C 1
C524	F 2	Y28 . Speaker, left front	C 1
C525	A 5	Y213 . Tweeter, left front	E 5