Item	Part Number	Description
1	14A103	Wiring harness – Engine room
2	14N066	Wiring harness – right front door
3	14A333	Wiring harness – Body 2
4	14A507	Wiring harness – Sliding door
5	13N850	Wiring harness – Rear defogger ground wire
6	9A350	Wiring harness – Fuel pump
7	14659	Wiring harness – Back door
8	13A576	Wiring harness – Trailer tow sub assembly
9	14A318	Wiring harness – Back door 2
10	13B711	Wiring harness – Room lamp
11	14N104	Wiring harness – Main
12	14B188	Wiring harness – left front door
13	14A068	Central Junction Box (CJB) (14A068)
14	2B373	ABS control module (2C219)
15	14A120	Wiring harness – Battery (10655) (+)
16	14301	Wiring harness – Battery (10655) (–)
17	–	Battery Junction Box (BJB)
18	–	Engine Compartment Relay Box
19	12B637	Wiring harness – Engine controls sub assembly
20	10C307	Wiring harness – Alternator
21	13K197	Wiring harness – Autolamp sub assembly
22	12A522	Wiring harness – Engine controls

Item	Part Number	Description
23	18C629	Wiring harness – Heater blower switch jumper
24	9F759	Wiring harness – Evaporative (EVAP) sub assembly
25	–	Driver seat module (14C718)
26	14A699	Wiring harness – Front seat, left (memory)
27	14A699	Wiring harness – Front seats (power)
28	14B095	Wiring harness – Air bag disconnect
29	14A664	Control assembly – Air bag
30	19D887	Wiring harness – Electronic Automatic Temperature Control (EATC) sub assembly
31	7A488	Wiring harness – Transmission controls
32	–	Wiring harness – Engine 2
33	12B559	Wiring harness – Knock sensor (12A699) sub assembly
34	12A650	Powertrain Control Module (PCM) (12A650)
35	9F812	Speed control actuator module
36	19980	Electronic Automatic Temperature Control (EATC) module (19980)
37	–	Lighting control module
38	14B023	Wiring harness – Air bag
39	12A565	Transaxle Control Module (TCM)
40	–	Smart Entry Control (SEC)/Timer module
41	VF3862	Wiring harness – Center console