C146b (GY)

12A522

P54
Distributor



F02137

Pin	Circuit	Circuit function
1	AV90 (BN)	Voltage supplied in Start and Run (overload protected)
2	AV94 (GN)	Distributor, Ignition coil, return

C148 (GY)

12B637

B10
Engine Coolant
Temperature (ECT)
sensor (12A648)



F02137

Pin	Circuit	Circuit function
1	AV92 (BK/YE)	signal, return
2	AV18 (LG/RD)	Engine Coolant Temperature (ECT) sensor (12A648), input