## Battery Junction Box (BJB) (14A003)

| Fuse | Amps | Circuits protected |
|---|---|---|
| F1.1 | 5 | Hydro max module |
| F1.2 | 10 | A/C clutch relay |
| F1.3 | 20 | 4R100 transmission, Oxygen sensor (O2S), EVAP canister purge valve |
| F1.4 | 5 | Powertrain Control Module (PCM) (12A650) |
| F1.5 | 15 | Fuel pump relay, Powertrain Control Module (PCM) (12A650), A/C clutch relay, Mass Air Flow (MAF) sensor (12B579), Fuel injectors, Idle air control valve (IAC) (9F715) |
| F1.6 | 20 | Main light switch (11654) |
| F1.7 | 15 | Digital Transmission Range (DTR) sensor (7F293) |
| F1.8 | 10 | Brake pressure switch (2B264), Brake pedal position switch (13480) |
| F1.9 | 5 | Instrument cluster |
| F1.10 | 20 | Daytime running lamps resistor |
| F1.11 | 30 | Ignition coil, Ignition transformer capacitor, PCM power relay |
| F1.12 | 20 | Trailer exterior lamp relay, Trailer tow relay, reversing lamp |
| F1.13 | 30 | Trailer electronic brake control module |
| F1.14 | 60 | Central Junction Box (CJB) (14A068) |
| F1.15 | – | not used |
| F1.16 | 60 | ABS control module (2C219) |
| F1.17 | – | not used |
| F1.18 | 20 | Horn relay |
| F1.19 | – | not used |
| F1.20 | 40 | PCM power relay |
| F1.21 | 20 | Fuel pump relay |
| F1.22 | 20 | Cigar lighter, Data Link Connector (DLC) (14489) |
| F1.23 | 40 | Blower motor relay |
| F1.24 | 40 | Central Junction Box (CJB) (14A068) |
| F1.25 | 50 | Ignition switch (11572) |
| F1.26 | 60 | Ignition switch (11572) |
| F1.27 | 30 | Multifunction switch (13K359), Main light switch (11654) |
| F1.28 | – | not used |
| F1.29 | 60 | Hydro max relay |