92-3 EXTERIOR LAMPS

EXPEDITION

* HEADLAMP SWITCH IN PARK OR HEAD OR PARK LAMP RELAY CLOSED

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C246	13-26



Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.