Battery Junction Box (BJB)

		Fuse number										
		1	2	3	4	5	6	7	8	9	10	11
		40A	30A				50A	40A	30A	20A	10A	30A
206-09A-00	Anti–Lock Control											●
206-09B-00	Anti–Lock Control – Anti–Wheelspin Control											●
206-09C-00	Anti–Lock Control – Anti–Wheelspin Control and Interactive Vehicle Dynamics (IVD)											●
303-03-00	Engine Cooling		●				●			●		
303-04D-00	Fuel Charging and Controls – ZETEC–E									●		
303-04E-00	Fuel Charging and Controls – SPI									●		
303-06D-00	Starting System – ZETEC–E								●			
303-06E-00	Starting System – SPI								●			
303-07D-00	Engine Ignition – ZETEC–E											
303-07E-00	Engine Ignition – SPI											
303-14D-00	Electronic Engine Controls – ZETEC–E								●	●		
303-14E-00	Electronic Engine Controls – SPI								●	●		
310-03-00	Vehicle Speed Control									●		
412-00-00	Climate Control System – General Information		●				●			●		
412-02-00	Heating/Defrosting											
413-00-00	Instrument Cluster and Panel Lighting – General Information											
413-01-00	Instrument Cluster											
413-06-00	Horn											
414-02-00	Generator and Regulator										●	
415-01-00	Audio Unit											
415-03-00	Speakers											
417-01-00	Exterior Lighting											
417-02-00	Interior Lighting											
417-04-00	Daytime Running Lamps											
418-00B-00	Module Communications Network, Diagnostic										●	
419-01A-00	Anti–Theft – Active											
419-01B-00	Anti–Theft – Passive								●	●		
419-10-00	Multifunction Electronic Control Modules											
		1	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**	**11**
		40A	30A				50A	40A	30A	20A	10A	30A