Current Flow (1)

Each cell normally starts with the component that powers the circuit such as a fuse or the ignition switch. Current flow is shown from the power source at the top of the page to ground at the bottom of the page. In order to concentrate on the essential parts, power supply and ground connections are sometimes simplified by a dashed line in the schematics. A full representation of the power supply of a fuse or the power distribution from a fuse to various components is given in cell 13 “Power Distribution”. Full representation of the ground connections are shown in cell 10 “Grounds”.

Switch Positions (2)

Within the schematic, all switches, sensors and relays are shown “at rest” (as if the Ignition Switch were OFF).

Splices (3)

A dashed line indicates that the splice is not shown completely. A reference is given to the page where the splice appears in full. It is also listed in the Index.

Component Referencing (4)

Each component on a schematic has a reference to the component location view for that component. It is located to the right of each component.

Component Names, Notes and Base Part Numbers (5)

Component names are placed on the right hand side of each component. Any notes that describe switch positions or operating conditions follow the name. Descriptions of the internals of the component are also included here. The page where the component appears in full is listed in the Index. The base part number for a component is listed in parentheses next to or under a component. These part numbers will appear any place the component name appears in the publication.

Component Identification Numbers (6)

Each component on each schematic has a component identification number located to the upper right hand side of the component. By finding this number in the Component Location Chart, the Component Location View for that component can easily be found.

