Master window adjust switch (14529) (continued)

Component testing procedure

Circuit to test	Connect self–powered test light or ohmmeter to terminals	Move switch to these positions	A good switch will indicate
Power and Ground Checks Before Any Other Tests	C504a, 2, and C504a, 3 C504a, 2, and C504a, 4 C504a, 2, and C504a, 8 C504a, 2, and C504b, 1 C504a, 2, and C504b, 2 C504a, 2, and C504b, 3 C504a, 2, and C504b, 4 C504a, 2, and C504b, 5 C504a, 2, and C504b, 6	All Eight Window Switches (at rest)	Closed circuit
Left front window circuit	C504a, 6 and C504a, 8	Up	Closed circuit
Right front window circuit	C504a, 3 and C504a, 6	Down	Closed circuit
	C504a, 4 and C504a, 6	Up	Closed circuit
Left rear window circuit	C504a, 6 and C504b, 6	Down	Closed circuit
	C504a, 6 and C504b, 5	Up	Closed circuit
Right rear window circuit	C504a, 6 and C504b, 2	Down	Closed circuit
	C504a, 6 and C504b, 3	Up	Closed circuit
	C504a, 6 and C504b, 4	Lock	Open circuit
		Unlock	Closed circuit