C601

14N066

Y18
Speaker, right front
(18808)



F02263

Pin	Circuit	Circuit function
1	RA52 (BU)	Speaker, right front (18808)
	RA42 (BU)	Speaker, right front (18808)
2	RA53 (YE)	Speaker, right front (18808)
	RA43 (YE)	Speaker, right front (18808)

C603 (BK)

14N066

M79
Power window motor, passenger side front (23394)



F02125

Pin	Circuit	Circuit function
1	PD12 (BU/YE)	Window motor, feed, Down
2	PD13 (BU/OG)	Window motor, feed, Up

C607 (BN)

14N066

N138
Door lock/unlock switch, passenger



F08145

Pin	Circuit	Circuit function
1	ID02 (PK/BK)	Illumination, Ground
2	PH41 (GN/OG)	Door unlock, switch sense
3	–	not used
4	PD18 (PK)	Illumination, feed
5	–	not used
6	–	not used
7	PH42 (GN/WH)	Door lock, switch sense
8	PHE7 (BK)	Ground