Battery Junction Box (BJB) (14A003), Before 2/18/02

Fuse	Amps	Circuits protected
F1.1	50A	Central Junction Box (CJB) (14A068)
F1.2	–	not used
F1.3	30A	Rear window motor
F1.4	–	not used
F1.5	–	not used
F1.6	50A	ABS control module (2C219)
F1.7	30A	PCM power relay
F1.8	–	not used
F1.9	–	not used
F1.10	–	not used
F1.11	50A	Starter relay (11450), Ignition switch (11572)
F1.12	–	not used
F1.13	20A	Four–wheel drive control module
F1.14	–	not used
F1.15	–	not used
F1.16	40A	Blower motor relay
F1.17	30A	Rear window defrost relay
F1.18	–	not used
F1.19	–	not used
F1.20	–	not used
F1.21	10A	Powertrain Control Module (PCM) (12A650)
F1.22	15A	Horn relay
F1.23	20A	Fuel pump relay
F1.24	25A	Multifunction switch, Main light switch (11654)
F1.25	10A	A/C clutch relay

Fuse	Amps	Circuits protected
F1.26	–	not used
F1.27	20A	Power point, rear (19G247)
F1.28	30A	ABS control module (2C219)
F1.29	15A	Fog lamp relay
F1.30	–	not used
F1.31	15A	Daytime Running Lamps
F1.32	–	not used
F1.33	15A	Main light switch (11654), Park lamp relay – Sport Trac
F1.34	15A	Rear wiper relay – Sport
F1.35	–	not used
F1.36	–	not used
F1.37	–	not used
F1.38	10A	Headlamp, left (13008)
F1.39	–	not used
F1.40	–	not used
F1.41	15A	Evaporative emission (EVAP) canister vent valve (9F945), Heated Oxygen Sensor (HO2S) #21 (9G444), Heated Oxygen Sensor (HO2S) #11 (9G444), Heated Oxygen Sensor (HO2S) #12 (9F472), 5R55E Transmission
F1.42	10A	Headlamp, right (13008)
F1.43	–	not used
F1.44	–	not used
F1.47A	20A c. b.	Window safety relay