Battery Junction Box (BJB) -8

		Fuse number										
		1	2	3	4	5	6	7	8	9	10	11
		40A	30A				50A	40A	30A	20A	10A	30A
206-09A-00	Anti–Lock Control											●
206-09B-00	Anti–Lock Control – Anti–Wheelspin Control											●
206-09C-00	Anti–Lock Control – Stability Assist											●
303-03-00	Engine Cooling		●				●			●		
303-04B-00	Fuel Charging and Controls – ZETEC–E									●		
303-04E-00	Fuel Charging and Controls – SPI									●		
303-04G-00	Fuel Charging and Controls – Duratec–ST									●		
303-06-00	Starting System								●			
303-07B-00	Engine Ignition – ZETEC–E											
303-07E-00	Engine Ignition – SPI											
303-07G-00	Engine Ignition – Duratec–ST									●		
303-14B-00	Electronic Engine Controls – ZETEC–E								●	●		
303-14E-00	Electronic Engine Controls – SPI								●	●		
303-14G-00	Electronic Engine Controls – Duratec–ST								●	●		
310-03-00	Vehicle Speed Control									●		
412-02A-00	Heating and Ventilation											
412-03A-00	Air Conditioning											
413-00-00	Instrument Cluster and Panel Illumination											
413-01-00	Instrument Cluster											
413-06-00	Horn											
414-02-00	Generator and Regulator										●	
415-01-00	Audio Unit											
415-03-00	Speakers											
417-01-00	Exterior Lighting											
417-02-00	Interior Lighting											
417-04-00	Daytime Running Lamps											
418-00-00	Module Communications Network											
419-01A-00	Anti–Theft – Active											
		1	2	3	4	5	6	7	8	9	10	11
		40A	30A				50A	40A	30A	20A	10A	30A