## Battery Junction Box (BJB) (14A003)

| Fuse | Amps | Circuits protected |
|---|---|---|
| F1.1 | 15A | Main light switch (11654), Remote keyless entry module (15K602) |
| F1.2 | 25A | VP–44 relay, Fog lamp relay |
| F1.3 | 10A | Generator |
| F1.4 | 15A | Windshield washer relay |
| F1.5 | 15A | Wait to start indicator, Cummins engine control module |
| F1.6 | 20A | Cummins engine control module, Cat engine control module |
| F1.7 | 15A | Brake pedal position switch (13480), Brake pressure switch 1, Brake pressure switch 2, Stoplamp switch 2, Stoplamp switch 1 |
| F1.8 | 25A | Fuel heater relay |
| F1.9 | 30A | Auxiliary Junction Box (AJB), trailer tow |
| F1.10 | 15A | Shift control modulator relay |
| F1.11 | 20A | Vehicle Interface Module (VIM), Allison 2000/2400 control unit |
| F1.12 | 10A | Remote keyless entry module (15K602) |
| F1.13 | 10A | Park brake adjust switch |
| F1.15 | 7.5A | Auxiliary Junction Box (AJB), trailer tow |
| F1.16 | 10A | Allison 2000/2400 control unit |
| F1.17 | 5A | Radio (18806) |
| F1.21 | 10A | Hydro max pump motor, Generic Electronic Module (GEM) (14B205) |
| F1.101 | 40A | ABS relay |
| F1.102 | 20A | Ignition switch (11572) |
| F1.103 | 50A | Ignition switch (11572) |
| F1.104 | 20A | Power point (19N236) |
| F1.105 | 20A | Door lock switch, passenger side (14028), Door lock switch, driver side (14028), Driver door unlock relay, Door lock relay, Door unlock relay |
| F1.106 | 30A | Main light switch (11654), Multifunction switch |
| F1.107 | 50A | Central Junction Box (CJB) (14A068) |
| F1.108 | 40A | Fuel heater relay |
| F1.109 | 40A | Power window relay |
| F1.110 | 30A | Seat adjust switch, driver side front (14A701) |
| F1.111 | 30A | Trailer tow relay, parking lamp |
| F1.112 | 40A | Blower motor relay |

| Fuse | Amps | Circuits protected |
|---|---|---|
| F1.113 | 30A | Heated seat module, driver side front, Heated seat module, passenger side front |
| F1.114 | 30A | |
| F1.115 | 40A | Central Junction Box (CJB) (14A068), Ignition switch (11572) |
| F1.116 | 30A | Turn relay, left, Turn relay, right, Stop lamp relay, Trailer tow relay, reversing lamp |
| F1.117 | 20A | PCM power relay |
| F1.118 | 30A | Injector Driver Module (IDM) power relay |
| F1.119 | 60A | Auxiliary Junction Box (AJB), trailer tow, ABS control module (2C219) |
| F1.120 | 60A | Auxiliary Junction Box (AJB), trailer tow, Hydro max relay |