F2.6 90–5
F2.7 13–8
F2.9 13–5
F2.10 13–4
F2.11 13–10
F2.12 90–5
F2.13 13–8
F2.14 13–8
F2.15 13–5
F2.16 13–4
F2.17 13–10
F2.19 13–8
F2.21 13–5
F2.25 85–4
F2.26 13–7
F2.31 85–4
F2.32 13–7
F2.35 85–4
F2.38 13–7
F2.41 13–11
Fuel pump 25–5
Fuel pump relay 25–4
Fusible link A 13–1
Fusible link B 13–1
Fusible link C 13–1
Fusible link D 13–1
G103 10–1
G105 10–2
G108 10–2
G200 10–4
G204 10–4
G401 10–5
Generator 12–1
Headlamp relay 85–3
Heated Oxygen Sensor (HO2S) #11 (9G444) 25–8
Heated Oxygen Sensor (HO2S) #21 (9G444) 25–8
Horn relay 44–1
Hydro max flow switch 47–1
Hydro max module 47–1
Hydro max pump motor 47–1
Hydro max relay 47–1
Idle air control valve (IAC) (9F715) 25–11
Ignition switch (11572) 13–6
Ignition transformer capacitor 1 (18801) 21–2
Ignition transformer capacitor 2 (18801) 21–3
Inertia Fuel Shutoff (IFS) switch (9D362) 25–5
Injector 1 (9F593) 25–6
Injector 10 (9F593) 25–7
Injector 2 (9F593) 25–6
Injector 3 (9F593) 25–6
Injector 4 (9F593) 25–6
Injector 5 (9F593) 25–6
Injector 6 (9F593) 25–7
Injector 7 (9F593) 25–7
Injector 8 (9F593) 25–7
Injector 9 (9F593) 25–7
Instrument cluster 60–2
Interior lamp relay 89–1
Knock sensor (12A699) 25–11
Main light switch (11654) 13–11
Mass Air Flow (MAF) sensor (12B579) 25–3
Multifunction switch (13K359) 90–2
Oil pressure switch (9278) 60–5
Output Shaft Speed (OSS) sensor (7M101) 25–9
Parking brake switch (15A851) 60–3
PCM Module power diode 25–4
PCM power relay 25–4
Powertrain Control Module (PCM) (12A650) 25–3
Rear axle speed sensor (4B409) 3 channel 42–2
S102 10–2
S102 13–1
S103 60–3