Fuse	Amps	Circuits protected
F1.01	10	Auxiliary coolant pump relay, A/C clutch relay, Coolant control valve solenoid (18495)
F1.02	–	not used
F1.03	15	Fog lamp relay
F1.04	15	Horn relay
F1.05	20	Mass Air Flow (MAF) sensor (12B579), Hydraulic fan solenoid (8K621), Fuel injectors, Inlet air control valve solenoid
F1.06	15	Speed control servo (9C735), Evaporative emission (EVAP) canister vent valve (9F945), Electr. Vacuum Regulator (EVR) solenoid valve, Automatic transmission (7C078), EVAP canister purge valve, Inlet Manifold Runner Control (IMRC) module
F1.07	–	not used
F1.08	–	not used
F1.09	–	not used
F1.10	5	Inlet air control valve solenoid
F1.11	15	A/C clutch relay, Heated Oxygen Sensor (HO2S) #21 (9F472), Heated Oxygen Sensor (HO2S) #11 (9F472), Heated Oxygen Sensor (HO2S) #22 (9G444), Heated Oxygen Sensor (HO2S) #12 (9G444), Air pump relay, Vacuum diverter valve solenoid

Fuse	Amps	Circuits protected
F1.12	10	Coil On Plug (COP) 1 (12029), Coil On Plug (COP) 2 (12029), Coil On Plug (COP) 3 (12029), Coil On Plug (COP) 4 (12029), Coil On Plug (COP) 5 (12029), Coil On Plug (COP) 6 (12029), Coil On Plug (COP) 7 (12029), Coil On Plug (COP) 8 (12029), Ignition transformer capacitor 1 (18801), Ignition transformer capacitor 2 (18801),
F1.13	30	Heated wiper park relay
F1.14	30	ABS control module (2C219), ABS test connector
F1.15	–	not used
F1.16	30	Blower motor relay
F1.17	20	Air pump relay
F1.18	40	PCM power relay, COPS & Heated Oxygen Sensor (HO2S) relay, F1.10
F1.19	–	not used
F1.20	30	Windshield wiper relay
F1.21	30	Starter relay (11450)
F1.22	30	ABS control module (2C219)
F1.23	–	Fuse plug
F1.24	–	not used