PICKUP

*** SHORTING BARS CONNECT HARNESS TERMINALS WHEN THE HARNESS IS DISCONNECTED.**

MULTIPLEX COMMUNICATION NETWORK
PAGE 14-2

70 LB/WH
C223

Warning
Do not attempt to diagnose or troubleshoot air bag circuitry without consulting the Workshop Manual. Improper troubleshooting could cause the air bags to deploy inadvertently, causing injury.

AIR BAG DIAGNOSTIC MODULE
151–8 F6

SOLID STATE

AIR BAG DRIVER FEED MONITOR	AIR BAG DRIVER RETURN	AIR BAG PASSENGER FEED MONITOR	AIR BAG PASSENGER RETURN	19 ISO 9141 LINK	DEDICATED GROUND	AIR BAG DEACTIVATION SWITCH LAMP DRIVER	AIR BAG DEACTIVATION SWITCH SENSE
1	15	14	28		22	8	9

HOT IN RUN

614 GY/OG — 615 GY/WH — C238F / C238M — * SHORTING BAR — * SHORTING BAR
AIR BAG SLIDING CONTACT
C224F / C224M — * SHORTING BAR
DRIVER AIR BAG
151–8 F2

607 LB/OG — 616 PK/BK — C220F / C220M — * SHORTING BAR — * SHORTING BAR
PASSENGER AIR BAG
151–8 C10

Electronically connects steering wheel controls to body harness.

0V — * SHORTING BARS
1203 BK/LB — 1113 YE/LG — 1112 WH/LB — C223

CENTRAL JUNCTION BOX
PAGE 13-31
2 — 22 — 34 — 10A

298 VT/OG — C242a
12V (RUN) — C226

PASSENGER AIR BAG DEACTIVATION SWITCH
151–8 A9
500Ω — 1KΩ

0V — C226
649 BK/OG — S202
1203 BK/LB — G203

SEE GROUNDS
PAGE 10-22

REVISED