-61

C451

A11
Radio

Pin	Circuit	Circuit Function
1	8-MD24 (WH/GN)	Sensor signal (X–direction, forward, upward)
2	–	not used
3	–	not used
4	29-MD15 (OG/BK)	Battery voltage, hot at all times (overload protected)
5	91-MD34 (BK/YE)	Ground (clean ground)
6	29S-LK34 (OG/BK)	Battery voltage, hot at all times (overload protected), switched
7	75-MD15 (YE/GN)	Battery voltage, hot in Run and Accessory only
8	91-MD15 (BK/GN)	Ground (clean ground)

C453

A11
Radio

Pin	Circuit	Circuit Function
1	8-MD18 (WH)	Sensor signal (X–direction, forward, upward)
2	10-MD18 (GY)	Sensor signal (Y–direction, reverse, downward)
3	8-MD17 (GY/RD)	Sensor signal (X–direction, forward, upward)
4	10-MD17 (GY/RD)	Sensor signal (Y–direction, reverse, downward)
5	8-MD10 (WH/BK)	Sensor signal (X–direction, forward, upward)
6	10-MD10 (GY/BK)	Sensor signal (Y–direction, reverse, downward)
7	8-MD11 (WH/VT)	Sensor signal (X–direction, forward, upward)
8	10-MD11 (GY/WH)	Sensor signal (Y–direction, reverse, downward)