Fuse	Amps	Circuits protected
F1.01	10	A/C clutch relay, Auxiliary coolant pump relay, Coolant control valve solenoid (18495)
F1.02	15	Heated wiper park relay
F1.03	10	Driving lamp, left (13411), Driving lamp, right (13411)
F1.04	15	Horn relay
F1.05	20	Mass Air Flow (MAF) sensor (12B579), Inlet air control valve solenoid, Hydraulic fan solenoid (8K621), Injector 1 (9F593), Injector 2 (9F593), Injector 3 (9F593), Injector 4 (9F593), Injector 5 (9F593), Injector 6 (9F593), Injector 7 (9F593), Injector 8 (9F593)
F1.06	15	Speed control servo (9C735), Evaporative emission (EVAP) canister vent valve (9F945), Electr. Vacuum Regulator (EVR) solenoid valve, Automatic transmission (7C078), EVAP canister purge valve
F1.07	–	not used
F1.08	20	Power point (19N236)
F1.09	–	not used
F1.10	10	not used
F1.11	15	A/C clutch relay, Heated Oxygen Sensor (HO2S) #11 (9F472), Heated Oxygen Sensor (HO2S) #21 (9F472), Heated Oxygen Sensor (HO2S) #12 (9G444), Heated Oxygen Sensor (HO2S) #22 (9G444)

Fuse	Amps	Circuits protected
F1.12	10	Coil On Plug (COP) 1 (12029), Coil On Plug (COP) 2 (12029), Coil On Plug (COP) 3 (12029), Coil On Plug (COP) 4 (12029), Ignition transformer capacitor 2 (18801), Coil On Plug (COP) 5 (12029), Coil On Plug (COP) 6 (12029), Coil On Plug (COP) 7 (12029), Coil On Plug (COP) 8 (12029), Ignition transformer capacitor 1 (18801)
F1.13	–	not used
F1.14	30	ABS control module (2C219), ABS test connector
F1.15	–	not used
F1.16	30	Blower motor relay
F1.17	–	not used
F1.18	40	PCM power relay, COPS & Heated Oxygen Sensor (HO2S) relay
F1.19	–	not used
F1.20	–	not used
F1.21	30	Starter relay (11450)
F1.22	30	ABS control module (2C219)
F1.23	–	Wiper run/park relay, Wiper high/low relay, Windshield wiper motor (17508), Windshield wiper relay
F1.24	30	Windshield wiper relay