C142 (GY)

12A522

R57
Resistor



F02147

Pin	Circuit	Circuit Function
1	AV94 (GN)	Distributor, Ignition coil, return
2	AV03 (WH)	Distributor, Ignition coil, return

C143 (BK)

12A522

N96
Power steering pressure switch

F01035

Pin	Circuit	Circuit Function
1	AV12 (PK)	Power steering pressure switch, input

C144 (WH)

12B637

B208
Heated Oxygen Sensor (HO2S), front



F03129

Pin	Circuit	Circuit Function
1	ES10 (BK)	Heated Oxygen Sensor (HO2S), front, heater
2	AW30 (LG)	signal, return
3	AW31 (BU/YE)	Voltage supplied in Start and Run (overload protected)

C146a (GY)

12A522

P54
Distributor



F06189

Pin	Circuit	Circuit Function
1	AV01 (BU)	Distributor, Transistor, return
2	EP90 (BK)	Ground
3	AV30 (WH)	Camshaft position sensor, return
4	AV31 (OG)	Camshaft position sensor, input
5	AV78 (BK/WH)	Voltage supplied in Start and Run (overload protected)
6	ES93 (BK/RD)	Ground

C146b (GY)

12A522

P54
Distributor

F02137

Pin	Circuit	Circuit Function
1	AV90 (BN)	Voltage supplied in Start and Run (overload protected)
2	AV94 (GN)	Distributor, Ignition coil, return

C148 (GY)

12B637

B10
Engine Coolant Temperature (ECT) sensor

F02137

Pin	Circuit	Circuit Function
1	AV92 (BK/YE)	signal, return
2	AV18 (LG/RD)	Engine Coolant Temperature (ECT) sensor, input