Fuse	Amps	Circuits protected
F4.01	15	Rear Electronic Module (REM)
F4.02	10	Turn lamp, right rear, License lamps (13550)
F4.03	5	Lamp assembly, left rear (13405), Tail lamp, left
F4.04	10	Fuel door release solenoid, Luggage compartment lamp (13A756)
F4.05	10	Map reading lamps, Vanity mirror lamp, left (04100), Vanity mirror lamp, right (04100), Footwell lamp, left front (13411), Footwell lamp, right front, Door entry lamp, left front (13776), Door entry lamp, right front (13776), Glove box lamp (14413), Interior lamp, rear
F4.06	10	Reversing lamps, Turn lamp, left rear
F4.07	5	Tail lamp, right, Lamp assembly, right rear (13404), Trailer exterior lamp relay
F4.08	10	High mounted stop lamp
F4.09	5	Exterior rear view mirror, driver side (17682), Exterior rear view mirror, passenger side (17683)
F4.10	20	Power point, console (19N236)
F4.11	15	Heated seat module, passenger side front, Heated seat module, driver side front
F4.12	–	not used
F4.13	–	not used
F4.14	5	CD changer (18D806), Cellular phone module, Vehicle Emergency Message System (VEMS) module

Fuse	Amps	Circuits protected
F4.15	5	Generator
F4.16	20	Roof opening panel module (502D70)
F4.17	15	Fuel pump relay
F4.18	20	Subwoofer amplifier (18C804)
F4.19	20	Rear Electronic Module (REM)
F4.20	20	Driver Door Module
F4.21	20	Lumbar adjust switch, left front (14B691), Driver seat module (14C718), Seat adjust switch, driver side front (14A701)
F4.22	20	Ignition switch (11572)
F4.23	30	SSP 4 relay
F4.24	30	SSP 3 relay
F4.25	40	F2.06, F2.07, F2.18, F2.19, F2.20, F2.32, F2.34, F2.35
F4.26	20	Front Electronic Module (FEM) (13C788)
F4.27	30	SSP 1 relay
F4.28	20	Seat adjust switch, passenger side front, Lumbar adjust switch, right front
F4.29	30	Rear window defrost relay
F4.30	20	Rear Electronic Module (REM)
F4.31	20	Ignition switch (11572)
F4.32	30	SSP 2 relay