C2131a

14401

A304
Air suspension module (3C142)



F16021

Pin	Circuit	Circuit function
11	–	not used
12	419 (DG/LG)	Air suspension module (3C142), to, Instrumentation and Warning System
13	–	not used
14	1115 (TN/WH)	Air suspension module (3C142), to, Right, rear, Solenoid
15	–	not used
16	–	not used
17	1114 (BN/BK)	Air suspension module (3C142), to, Left, rear, Solenoid
18	420 (DB/YE)	Air suspension module (3C142), to, Air suspension compressor relay, signal
19	–	not used
20	432 (BK/PK)	Air suspension module (3C142), Ground
27	933 (BK/OG)	Solenoid, Sensor, input, to, Air suspension module (3C142)
28	429 (PK/LG)	Air suspension height sensor (3C131), rear, feed
29	70 (LB/WH)	ISO Bus
30	421 (PK)	Air suspension compressor assembly, Vent solenoid, to, Air suspension module (3C142)
31	–	not used
32	57 (BK)	Ground

C2131b

14401

A304
Air suspension module (3C142)



F16021

Pin	Circuit	Circuit function
1	418 (DG/YE)	Voltage supplied at all times (overload protected)
2	633 (RD)	Steering position sensor (18B015), to, Air suspension module (3C142), Terminal (–) A
3	679 (GY/BK)	Vehicle Speed Sensor (VSS) +
4	1003 (GY/YE)	Voltage in Run (overload protected)
5	999 (LB/WH)	GEM/RAP door ajar, signal
6	637 (DB/WH)	Air suspension module (3C142), to, Powertrain Control Module (PCM) (12A650)
7	–	not used
8	–	not used
9	428 (OG/PK)	Powertrain Control Module (PCM) (12A650), to, Air suspension module (3C142), signal
10	810 (RD/LG)	Brake pedal position switch (13480), input
21	418 (DG/YE)	Voltage supplied at all times (overload protected)
22	634 (BN)	Steering position sensor (18B015), to, Air suspension module (3C142), Terminal (+) B
23	1000 (RD/BK)	Voltage supplied in Start (overload protected)
24	–	not used
25	–	not used
26	934 (RD/YE)	Solenoid, Sensor, output, to, Air suspension module (3C142)