Fuse and Relay Information

Cell 11 “Fuse and Relay Information” contains a view of the fuse/relay box in which all fuses and relays are identified.



Power Distribution

Cell 13 “Power Distribution” shows the current feed circuit. The current path is shown from the battery to the ignition switch and to all fuses. It also shows the circuits protected by each fuse. The circuit is traced from the fuse to the component. All details (wires, splices, connectors) between the fuse and the first component are shown.