Components — Cell 151

Location	Page/coordinates
4R100 transmission transmission, RH side	1 – F 4
A/C clutch cycling pressure switch (19D594) engine, RH side	3 – E 3
A/C clutch field coil (19D798) engine, front, RH side	4 – E 3
A/C clutch relay in Battery Junction Box (BJB)	5 – A 2
A/C Compressor clutch diode engine, front, RH side	
A/C high pressure switch (19D594) engine, RH side	3 – E 3
ABS control module (2C219) inside frame rail, LH side	10 – E 4
Air bag sliding contact (14A664) Steering Column	7 – C 1
Auxiliary relay box 1 engine compartment, LH side	6 – D 1
Battery (10655) on frame rail, RH side	3 – E 1
Battery Junction Box (BJB) (14A003) in Battery Junction Box (BJB)	5 – A 1
Blower motor relay in Battery Junction Box (BJB)	5 – B 1
Brake differential pressure switch engine compartment, LH side	6 – E 3
Brake fluid level switch (2L414) engine compartment, LH side-without hydro max	5 – A 3
Brake pedal position switch (13480) behind dash panel	7 – E 5
Brake pressure switch (2B264) engine compartment, LH side-with hydro max	6 – B 3
Brake pressure switch (2B264) engine compartment, LH side-without hydro max	5 – A 3
Brake shift interlock (3Z719) Steering Column, LH side	7 – C 1
Brake warning indicator diode in Battery Junction Box (BJB)	5 – A 1
Camshaft position sensor (6B288) engine, front, LH side	2 – B 1
Central Junction Box (CJB) (14A068) in Central Junction Box (CJB)	9 – B 1
Coil On Plug (COP) 1 (12029) engine, RH side	3 – E 2
Coil On Plug (COP) 10 engine, RH side	1 – E 2
Coil On Plug (COP) 2 (12029) engine, RH side	3 – E 2
Coil On Plug (COP) 3 (12029) engine, RH side	3 – B 3
Coil On Plug (COP) 4 (12029) engine, RH side	3 – A 2
Coil On Plug (COP) 5 (12029) engine, RH side	3 – B 2
Coil On Plug (COP) 6 (12029) engine, LH side	1 – A 2
Coil On Plug (COP) 7 (12029) engine, LH side	1 – D 2
Coil On Plug (COP) 8 (12029) engine, LH side	1 – E 2
Coil On Plug (COP) 9 (12029) engine, LH side	1 – E 2
Crankshaft position sensor (6C315) engine, front, RH side	4 – B 5
Cylinder-head temperature sensor (6G004) top, front, Left, cylinder head	