• **DRIVEABILITY—FUEL PRESSURE RELIEF VALVE DISCONTINUED—VEHICLES EQUIPPED WITH 3.0L 2V AND 3.0L 4V DURATEC ENGINE** • **FUEL—FUEL PRESSURE RELIEF VALVE DISCONTINUED—VEHICLES EQUIPPED WITH 3.0L 2V AND 3.0L 4V DURATEC ENGINE**	**Article No. 02-11-1**

FORD: 2002 TAURUS

MERCURY: 2002 SABLE

Article **02-8-4** is being republished in its entirety to update the engine applications.

ISSUE

Vehicles equipped with the 3.0L 2V built after 4/8/2002 and vehicles equipped with the 3.0L 4V Duratec built after 5/8/2002 will no longer have the Fuel Pressure Relief Valve (Shrader Valve).

ACTION

To relieve or manually check fuel pressures, refer to the following Service Procedures for details.

SERVICE PROCEDURE

Service Procedure For Relieving Fuel Pressure

1. Remove the fuel pump relay in the engine compartment fuse box located in location "K-4"/C-1051.
2. Start the engine and allow idling until the engine stalls.
3. After the engine stalls, crank the engine for approximately five seconds to ensure the fuel injection supply manifold pressure has been released.
4. When fuel system service is complete, Install Fuel Pump Relay.
5. Cycle key and wait 3 seconds to re-pressurize the fuel system. Check for leaks before starting engine.

NOTE

IT MAY TAKE MORE THAN ONE KEY CYCLE TO RE-PRESSURIZE THE FUEL SYSTEM.

6. Start vehicle and check for leaks.

NOTE

IT IS POSSIBLE THAT A DTC MAY BE SET DUE TO THE PUMP RELAY BEING PULLED AND THE ENGINE STARTED AND RUN OUT OF FUEL. IF DTC'S ARE SET, CLEAR ALL DTC'S BEFORE RETURNING VEHICLE TO THE CUSTOMER.

Service Procedure For Manually Checking Fuel Pressure With Gauge

1. Remove the fuel pump relay in the engine compartment fuse box located in location "K-4"/C-1051.
2. Start the engine and allow idling until the engine stalls.
3. After the engine stalls, crank the engine for approximately five seconds to make sure the fuel injection supply manifold pressure has been released.
4. Disconnect fuel line at the fuel rail to chassis line pierce point, using special service tool number 310-D005 or equivalent.
5. Install Adaptor Spring Lock Coupling, special service tool number 310-D003 or equivalent.
6. Install fuel pressure gauge special service tool 310-012 or equivalent.
7. Install fuel pump relay.
8. Cycle key and wait 3 seconds to re-pressurize the fuel system. Check for leaks before starting engine.

NOTE

IT MAY TAKE MORE THAN ONE KEY CYCLE TO RE-PRESSURIZE THE FUEL SYSTEM.

Copyright © 2002 Ford Motor Company

9. Start and run engine to purge air from fuel system (Air trapped in the fuel system may effect test results).
10. Perform normal diagnostics and service repairs as needed.
11. After fuel system service is complete, relieve fuel system pressure using fuel pressure gauge relief valve.
12. Remove special service tools.
13. Re-connect fuel system lines.
14. Cycle key and wait 3 seconds to re-pressurize the fuel system. Check for leaks before starting engine.

NOTE
IT MAY TAKE MORE THAN ONE KEY CYCLE TO RE-PRESSURIZE THE FUEL SYSTEM.

15. Start vehicle and check for leaks.

NOTE
IT IS POSSIBLE THAT A DTC MAY BE SET DUE TO THE PUMP RELAY BEING PULLED AND THE ENGINE STARTED AND RUN OUT OF FUEL. IF DTC'S ARE SET, CLEAR ALL DTC'S BEFORE RETURNING VEHICLE TO THE CUSTOMER.

OTHER APPLICABLE ARTICLES: NONE
SUPERSEDES: 02-8-4
WARRANTY STATUS: INFORMATION ONLY
OASIS CODES: 404000, 490000, 497000, 499000, 603300, 607000, 698298, 803000