• **BODY—ACCESSING THE TONNEAU COVER ELECTRONIC CONTROL MODULE (ECU)** • **ELECTRICAL—ACCESSING THE TONNEAU COVER ELECTRONIC CONTROL MODULE (ECU)**	**Article No. 02-9-6**

LINCOLN: 2002 BLACKWOOD

ISSUE

This article provides step-by-step directions to get to the ECU without damaging the the Polished Metal Surfaces inside the Truck Box/Bed.

ACTION

Refer to the following procedure to access the ECU without damaging the bed panels, and then proceed to diagnose as necessary as covered in the Workshop Manual.

SERVICE PROCEDURE

MODULE REMOVAL PROCEDURE

1. Remove RH side Top Cap Trim from the top of the pickup Box Side.
2. Remove 6 (30 torx) screws from top of RH side stainless panel.
3. Remove hinge hider from RH stainless upper panel.
4. Remove emergency release bezel from RH D-Pillar (At Dutch Door) (2 screws).
5. Remove rear and RH side cove moulding by pulling adhesive from stainless.
6. Remove 4 (30 torx) bolts from RH stainless lower panel.
7. Pull stainless away from side 4 inches and unplug light bar at both ends.
8. Remove RH side stainless steel from unit.
9. Remove RH front cargo tie down.
10. Pull carpet back from RH side to give room to see front stainless bolts.
11. Remove 5 (8mm) bolts from front stainless lower panel.
12. Pull panel out 6 inches, get hand tool behind stainless, locate Module.
13. Remove 4 electrical connections from Module.
14. Remove 2 (10mm) bolts securing Module to frame and remove Module.
15. To re-install repeat procedure in reverse.

OTHER APPLICABLE ARTICLES: NONE
WARRANTY STATUS: INFORMATION ONLY
OASIS CODES: 108000, 111000, 190000, 203000, 205000, 290000

Copyright © 2002 Ford Motor Company