Get Started with Contiki

Step 1: Grab Instant Contiki Step 2: Start Cooja Step 3: Run Contiki in simulation

Step 4: Run Contiki on hardware Step 5: Now what?



Step 1: Grab Instant Contiki

Contiki is a very complex piece of software. Instant Contiki and Cooja makes Contiki easier to install and get started with.

About Instant Contiki

Instant Contiki is an entire Contiki development environment in a single download. It is an Ubuntu Linux virtual machine that runs in VMWare player and has Contiki and all the development tools, compilers, and simulators used in Contiki development installed.

Instant Contiki is so convenient that even hardcore Contiki developers use it.

We begin by downloading Instant Contiki, installing VMWare Player, and booting up Instant Contiki.

Download Instant Contiki

Download Instant Contiki. Get a coffee: it is a large file, just over 1 gigabyte. When downloaded, unzip the file, place the unzipped directory on the desktop.

Download Instant Contiki » (http://sourceforge.net/projects/contiki/files/Instant%20Contiki/)

Install VMWare Player


Download and install VMWare Player. It is free to download, but requires a registration. It might require a reboot of your computer, which is unfortunate but needed to get networking working.

Download VMWare Player » (http://www.vmware.com/go/downloadplayer/)

Start Instant Contiki


Boot Ubuntu

Start Instant Contiki by running InstantContiki2.6.vmx. Wait for the virtual Ubuntu Linux boot up.



Log in

Log into Instant Contiki. The password is user



Congratulations! Now that we have Instant Contiki up and running, we will start Cooja.

Step 2: Start Cooja


About Cooja

Cooja is the Contiki network simulator. Cooja allows large and small networks of Contiki motes to be simulated. Motes can be emulated at the hardware level, which is slower but allows precise inspection of the system behavior, or at a less detailed level, which is faster and allows simulation of larger networks.

We will now compile and start Cooja, the Contiki network simulator.

Open a terminal window

To start Cooja, first open a terminal window.



Start Cooja

In the terminal window, go to the Cooja directory:


cd contiki/tools/cooja


Start Cooja with the command:

ant run

Wait for Cooja to start

When Cooja first starts, it will first compile itself, which may take some time.





Now that Cooja is up and running, we can try it out with an example simulation.


Step 3: Run Contiki in simulation

About Cooja simulations

Cooja is a highly useful tool for Contiki development as it allows developers to test their code and systems long before running it on the target hardware. Developers regularly set up new simulations both to debug their software and to verify the behavior of their systems.


Create a new simulation

Create new simulation




Set simulation options

Cooja now opens up the **Create new simulation** dialog. In this dialog, we may choose to give our simulation a new name, but for this example, we'll just stick with My simulation. Click the **Create** button.




Simulation windows

Cooja brings up the new simulation. The Network window, at the top left of the screen, shows all the motes in the simulated network - it is empty now, since we have no motes in our simulation. The Timeline window, at the bottom of the screen, shows all communication events in the simulation over time - very handy for understanding what goes on in the network. The Mote output window, on the right side of the screen, shows all serial port printouts from all the motes. The Notes window on the top right is where we can put notes for our simulation. And the Simulation control window is where we start, pause, and reload our simulation.




Add motes to the simulation

Add motes




Create a new mote type

Cooja opens the Create Mote Type dialog, in which we can choose a name for our mote type as well as the Contiki application that our mote type will run. For this example, we stick with the suggested name, and instead click on the Browse... button on the right hand side to choose our Contiki application.




Find example Contiki application

We go to the directory [/home/user/contiki/examples/ipv6/simple-udp-rpl]. This directory holds a number of Contiki applications that provide examples for how to do simple UDP communication over IPv6.




Specify application C source file

Choose the file **broadcast-example.c**. This file contains a simple Contiki application that randomly broadcasts a UDP packet to its neighbors. Click the **Open** button to choose the file.




Compile Contiki and the application

Now Cooja will verify that the selected Contiki application compiles for the platform that we have selected. Click the **Compile** button. This will take some time the first time around, expect it to take a minute at least. The compilation output will show up in the white panel at the bottom of the window.




Create the mote type

Click the **Create** button to create the mote type. The window will close.




Add motes to simulation

Cooja will now ask us if we want to add motes from the newly created mote type to the simulation. We change the number of motes to add in the **Number of motes** field to 8.




Add the motes

We click the Add motes button to add the motes to the simulation.




Start the simulation

We can now see the 8 motes we added to the simulation in the **Network** window. Click the **Start** button to start the simulation.



Pause the simulation

We see printouts from the simulated motes appearing in the Mote output window. The Network window shows communication going on in the network. The Timeline window shows communication and radio events over time the small gray lines are ContikiMAC periodically waking the radio up. We can click the Pause button to pause the simulation.



Done!

Congratulations! We have now created your first Cooja simulation with Contiki nodes that send periodic IPv6/UDP packets with ContikiMAC sleepy router functionally.

Step 4: Run Contiki on hardware

About Contiki on hardware

Contiki has a build system that is intended to make it easy to run Contiki directly on hardware. The build system is designed to be the same across different hardware platforms, so that the build commands are familiar when switching hardware. The build system consists of a set of makefiles. The base makefile is contiki/Makefile.include, platform makefiles in contiki/platform/*/Makefile.platform and contiki/cpu/*/Makefile.cpu.

Connect the hardware

In this example, we assume you have a Zolertia Z1 (hardware.html) mote connected to a USB port of your PC. We first need to enable the Z1 in Instant Contiki, so that Instant Contiki is able to talk to it. This is done through the Virtual Machine menu in VMWare Player, followed by the Removable Devices menu item.

Open a terminal, go to the code directory

The Contiki build system is run in a terminal window. Open a terminal window and go to the Hello World example directory:

cd contiki/examples/hello-world

Compile Contiki and the application

We can now compile the Hello World application for our hardware platform. This also compiles the entire Contiki system, so it will take some time the first time around.

make TARGET=z1 hello-world

If you plan to compile more than once for the chosen platform, you can ask Contiki to remember your choice of hardware with the special savetarget maketarget. Do this now:

make TARGET=z1 savetarget

Upload Contiki to the hardware

Now we are ready to upload the compiled code to the hardware. We do this with the special %.upload maketarget like this:

make hello-world.upload

Note: If you see output along the lines of the following, that means that the Z1 mote has not been connected to Instant Contiki:

```
make z1-reset z1-upload
make[1]: Entering directory `/home/user/contiki/examples/hello-world'
make -k -j 20 z1-reset-sequence
make[2]: Entering directory `/home/user/contiki/examples/hello-world'
Done
make[2]: Leaving directory `/home/user/contiki/examples/hello-world'
make -j 20 z1-upload-sequence
make[2]: Entering directory `/home/user/contiki/examples/hello-world'
Done
make[2]: Leaving directory `/home/user/contiki/examples/hello-world'
make[1]: Leaving directory `/home/user/contiki/examples/hello-world'
rm hello-world.ihex
```

Check the connection to the PC, check the connection in VMWare Player, and try again.

Note that we could have done the compilation and uploading in one step: the <code>make hello-world.upload</code> target automatically compiles the application and Contiki before uploading it to the hardware.

See the Hello World output

Now that the code is burned onto the hardware device, we can check the serial port to see the output of the program. To see the serial port output of our connected mote, we run the following command:

```
make login
```

This will not show any output (except potentially a few garbage characters which sometimes seem to be inserted by VMWare) because the Hello World program has already finished. To see the output, press the reset button on the mote. Something like the following should show up:

```
Rime started with address 1.1

MAC 01:01:00:00:00:00:00:00 Contiki-2.6 started. Node id is set to 257.

CSMA ContikiMAC, channel check rate 8 Hz, radio channel 26

Starting 'Hello world process'

Hello, world
```

Done!

Congratulations! If you have completed all the steps in this tutorial, you have successfully been running Contiki both in simulation and on hardware. If everything worked, you might try to run the code we ran in simulation on hardware: upload the **broadcast-example** program in the **contiki/examples/ipv6/simple-udp-rpl/** directory to two hardware devices and look at them sending low-power wireless IPv6/UDP messages to each other.

Step 5: Now what?

Hardware

To see what your hardware options for Contiki are, or get hold of a hardware platform to run Contiki on, go to the hardware page:

Hardware » (hardware.html)

Source code

To dive into the Contiki source code, you can download the latest release or grab the current development version with git:

Download » (download.html)

Community

To engage with the Contiki developer community, go to the Contiki community page:

Community » (community.html)

License

To read the legal details of the Contiki open source license, go to the Contiki license page:

Open source » (license.html)

Resources

Read more about further Contiki resources:

Resources » (support.html)

Hosted by Thingsquare (http://thingsquare.com/)